


























Montážní návod / Assembly instruction

WI070 / WI071, WI080 / WI081, WI090 / WI091
WI100 / WI101, WI110 / WI111



	B	
	Min(mm)	Max(mm)
700x1900	685	700
800x1900	785	800
900x1900	885	900
1000x1900	985	1000
1100x1900	1085	1100

A**B****C****D**