



Modell	A1	A2	X1	X2	Y1	Y2	B1	B2	D	H
<i>KDD I 80Lx80R</i>	800	800	775-790	775-790	770-785	770-785	704	704	970	2000
<i>KDD I 80Lx90R</i>	800	900	775-790	875-890	770-785	870-885	704	804	1043	2000
<i>KDD I 80Lx100R</i>	800	1000	775-790	975-990	770-785	970-985	704	904	1120	2000
<i>KDD I 90Lx80R</i>	900	800	875-890	775-790	870-885	770-785	804	704	1043	2000
<i>KDD I 90Lx90R</i>	900	900	875-890	875-890	870-885	870-885	804	804	1111	2000
<i>KDD I 90Lx100R</i>	900	1000	875-890	975-990	870-885	970-985	804	904	1184	2000
<i>KDD I 100Lx80R</i>	1000	800	975-990	775-790	970-985	770-785	904	704	1120	2000
<i>KDD I 100Lx90R</i>	1000	900	975-990	875-890	970-985	870-885	904	804	1184	2000
<i>KDD I 100Lx100R</i>	1000	1000	975-990	975-990	970-985	970-985	904	904	1253	2000

